

# Collision Detector

## Installation & Technical Reference Manual



Automated NDT systems made simple

2319 Dunwin Drive, Unit 8, Mississauga, Ontario, L5L 1A3  
Phone 905-828-1313 Fax 905-828-0360 [www.utex.com](http://www.utex.com)



## Table of Contents

<b>About the Collision Detector</b>	<b>1</b>
What is a Collision Detector?	1
What kinds of applications can a Collision Detector be used for?	1
What is included in this Kit	1
<b>Assembly and Installation</b>	<b>2</b>
Enabling open-collector pullups and alarm	4
Mounting the Interface Unit	4
Adjustment	5
<b>Technical Reference</b>	<b>5</b>
General Specifications	5
<b>Diagram 1: Sensor Head Dimensions</b>	<b>6</b>
<b>Diagram 2: Interface Unit Dimensions</b>	<b>7</b>
<b>Appendix A - Connectors, Adjustments, and Switches</b>	<b>9</b>
<b>Appendix B - Troubleshooting</b>	<b>10</b>
<b>Appendix C - Output Schematic</b>	<b>11</b>
<b>Appendix D - Custom Contact Feelers</b>	<b>11</b>



## What is a Collision Detector?

The Collision Detector is a touch sensor designed to prevent damage to a scanning system or inspection components due to accidental collisions.

The Collision Detector detects when the scanner gets too close to the surface of a part using an omni-directional, low-force sensor. It sends a signal to the emergency stop circuit of a motor controller using a normally-open or normally-closed contact. The trip threshold is adjustable and the sensor head can withstand a load of up to 100 pounds. An operator can be alerted by an LED and audible alarm when the unit is tripped.

## What kinds of applications can a Collision Detector be used for?

The Collision Detector should be used with any robotic or automated machinery where collisions could cause damage to either the machinery or the part. Any scanner can benefit from having Collision Detectors installed to protect tank walls, bottoms, transducers, and inspection parts. The Collision Detector can also be used as a bottom sensor.

## What is included in this Kit

Sensor Head + 10 Ft cable	1
Contact Feeler, Loop	1
Contact Feeler, Straight	1
Interface Unit	1
Mounting Block, Delrin	1
Black Elastomers, short	2
Black Elastomers, long	2
Hex Key	1
Rubber feet	4
4 position terminal block, Male	1
3 position terminal block, Male	1
3 position terminal block, Female	1


# UTEX Collision Detector Manual

## Assembly and Installation

There are only four steps required to prepare the Collision Detector for operation.


1

Attach a contact feeler to the sensor head



2

Attach the sensor head to the search tube or scanner arm




# UTEX Collision Detector Manual

## Attach the sensor head... continued:

The means by which to mount the sensor head to a scanner will vary from scanner to scanner. A mounting block is supplied that may be appropriate for attaching the sensor head to the search tube of your scanner.


3

### Connect the cables to interface unit



4

### Configure pullups and the alarm



# UTEX Collision Detector Manual

## Configuring open-collector pullups and alarm

The Interface unit provides two open-collector outputs and an audible alarm.

- The Normally Open output sinks current to GND when the sensor trips (deflected)
- The Normally Closed output sinks current to GND when the sensor is not tripped (at rest)
- Each output can sink 300 mA when active
- Pullup resistors may be switched in to pull each output up to +5V when inactive (TTL operation)
- The alarm (when enabled) provides an audible tone when the sensor is tripped

To enable the pullup resistor for a particular output, slide the enable switch for the NO PULLUP or NC PULLUP to the right position. To disable a pullup, slide the switch to the left position.

**WARNING:** If a pull-up is enabled on an output, the open-circuit voltage on the input of the external equipment must not exceed +5 volts.

For a schematic of how the NO and NC outputs operate see **Appendix C**.

## Mounting the Interface Unit

The Interface unit should be mounted in a cabinet away from your tank. The Interface Unit is not waterproof, and should be kept dry and protected.

- The Interface Unit can be panel-mounted with four #6 or M4 screws (not included)
- Four rubber feet (included) can be used for non-permanent installations.

When mounting the unit remember to leave room on each end to plug in the sensor and signal cables.



## Adjustment

With the sensor head plugged into the interface unit, and DC power on, the threshold may be adjusted.

To aid in the adjustment of the trip point, the interface unit has an audio alarm that can sound when the trip point is reached. The alarm provides a convenient way of making the trip point adjustment without watching the LED, as well as providing an audible alert of a collision.

Status of Sensor	Action	Comment
At Rest	Turn trip Point CW until Status LED goes red, then turn CCW until it turns green	
Deflected	Status LED should turn red	Adjust Trip Point for desired amount of deflection

If the LED fails to change color, see the troubleshooting information in **Appendix B**


## Technical Reference

### General Specifications


Interface Unit dimensions	(Approx) 3.5"W x 5.2"L x 1.0"H for accurate dimensions see <b>diagram 2</b>	
Sensor Head dimensions	See <b>diagram 1</b>	
Electrical Power supply requirement	8 to 24 VDC 50 mA (typ)	
Outputs Maximum current: Maximum voltage	300 mA 30 V (output in off state)	
Forces and displacements Breakover moment Breakover force <sup>†</sup>	(typical) 0.16 Nm 125 g / 1.23 N	(typical) 22.7 ozf-in 4.4 ozf
Maximum angular displacement	10°	
Maximum axial displacement	3.6 mm	0.14 in
Cable:	3-conductor, 10 feet	

<sup>†</sup> Breakover force is measured at the ring of the Contact Feeler  
(UTEX part number AY11-004-005/001)

Diagram 1: Sensor Head Dimensions



# Diagram 2: Interface Unit Dimensions



# UTEX Collision Detector Manual

# UTEX Collision Detector Manual

## Appendix A

### Connectors, Adjustments, and Switches

#### Interface to Sensor head connector (5-position terminal block)

Position	Name	Function
1	SENSOR	Sensor input voltage (for test purposes)
2	REFERENCE	Threshold reference voltage output (for test purposes)
3	+5V	+5 VDC supply to sensor head
4	SENSOR IN	Input signal from sensor head
5	GND	Ground return for sensor head

#### Output and power connector (4-position terminal block)

Position	Name	Function
1	NC OUPUT	Open-collector output: low when sensor not deflected
2	NO OUTPUT	Open-collector output: low when sensor deflected
3	GND	Common return for power supply and outputs
4	+8-24VDC	+8 to +24 VDC supply input

#### Adjustment potentiometers

Position	Function	Location
R19	High limit of threshold	Not accessible with cover on
R20	Threshold adjust (trip point)	Accessible though opening in cover
R22	Low limit of threshold	Not accessible with cover on

#### Switches

Switch #	Name	Function
1	Enable alarm	Enables audio alarm when sensor head is deflected
2	Enable NO pullup	Connects 330 $\Omega$ pullup (to internal +5V) to NO output
3	Enable NC pullup	Connects 330 $\Omega$ pullup (to internal +5V) to NC output

# UTEX Collision Detector Manual

## Sensor head cable connector

The 3-conductor cable of the sensor head is terminated on a 5-position terminal block plug. In this 3-conductor cable, there is one conductor with yellow/green stripes, and two black wires numbered “1” and “2” at periodic intervals.

Position	Wire number	Function
1	N/A	Not used
2	N/A	Not used
3	2	+5 VDC supply to sensor
4	1	Voltage output from sensor
5	Yellow/Green	GND

## Appendix B


### Troubleshooting

Problem	Probable Cause	Solution
LED stays red over entire adjustment range.	Threshold range is too low.	1. Set trip point adjustment to midpoint of rotation. 2. Remove cover. 3. Turn R19 clockwise until LED changes to green. 4. Replace cover.
LED stays green over entire adjustment range.	Threshold range is too high.	1 Set trip point adjustment to midpoint of rotation. 2 Remove cover. 3 Turn R22 counterclockwise until LED changes to red. 4 Replace cover.
Trip point changes when sensor is attached to scanner.	Steel, iron, or other ferromagnetic metal located near the back of the sensor head may interfere with the magnetic field	Try: - Increase separation between metal and sensor - Adjust trip point - Adjust threshold range

# UTEX Collision Detector Manual


## Appendix C

### Output Schematic (NO or NC output)



## Appendix D

### Custom Contact Feelers



Examples of Custom Contact Feelers

Custom Contact Feelers can be built using 1/8" stainless rod.

# UTEX Collision Detector Manual

## UTEX SCIENTIFIC INSTRUMENTS INC.

### ONE YEAR LIMITED WARRANTY

Subject to each of the terms and conditions stated herein, UTEX SCIENTIFIC INSTRUMENTS INC. "UTEX" warrants to the original purchaser that should, in UTEX's judgement, the instrument prove defective by reason of improper workmanship and/or material, UTEX shall repair or replace, at its option, any defective part of the instrument without charge for the parts, for a period of one year from the date of the original purchase and shall, for such period, bear the entire labor expense for any warranty repair of the defective instrument or defective parts when such labor is performed at an authorized UTEX service center.

All parts used for replacement are warranted for the remainder of the original warranty period only. To obtain warranty service, the purchaser must notify an authorized UTEX service center of any alleged defect within the applicable warranty period.

1. **PROOF OF PURCHASE DATE IS REQUIRED WHEN REQUESTING WARRANTY SERVICE.** In order to obtain warranty service, the original purchaser must deliver the instrument to the nearest authorized UTEX service center. Shipping expenses are the purchaser's responsibility. The name and address of the nearest service center can be obtained from a UTEX dealer or by writing or calling UTEX at the address and telephone number provided. The original purchaser must present to the service center a sales receipt or other written evidence establishing proof and date of purchase of the instrument.
2. **THIS WARRANTY DOES NOT COVER** damage to the instrument caused by modification, alteration, physical abuse to, or misuse of, the instrument, by repair or service to the product by anyone other than an authorized UTEX service center; by operation in a manner contrary to the instructions which accompany the instrument; by freight damage; or by any other damage caused by circumstances beyond UTEX's control, such as lightning or fluctuation in electrical power. The purchaser is solely and totally responsible for installation and initial technical adjustments of the instrument; adjustment of user controls; and any required maintenance of the instrument. Please consult the operating instructions for information regarding user controls.
3. Any express warranty not provided herein, and any remedy which, but for this provision, might arise by implication or operation of law is hereby excluded and disclaimed. The implied warranties of merchantability and of fitness for any particular purpose are expressly limited to a term of one year.
4. Under no circumstances shall UTEX be liable to the original purchaser or any other person for any incidental, special or consequential damages, whether arising out of breach of warranty, breach of contract, or otherwise.
5. For the name of the nearest authorized UTEX service center, call 905-828-1313 or e-mail to [tech-support@utex.com](mailto:tech-support@utex.com).
6. **Do not send your instrument** without first contacting UTEX Scientific Instruments Inc. for your return materials authorization number (RMA).



