

The UTEX Motion Pendant



Operation:

- Press an axis selection button to enable motion
- Turn the wheel to move the axis in fixed increments
- Push and turn the wheel to drive the axis at a speed and direction relative to the knob rotation
- Release the wheel to stop all motion